

DORCY®

1800L POWER LANTERN RECHARGEABLE + POWER BANK

Lantern Parts



Carabiner Clip (On top)

Includes:
3600 mAh Lithium-ion
rechargeable battery

4 Mode Power Switch:

- HIGH
- HIGH-MEDIUM
- MED-LOW
- LOW

Carabiner Clip (On bottom)



Rechargeable:

- A) Equipped with a micro USB cable for quick and convenient charging (Included)
- B) Red Light Blinking: Lantern is charging
- C) Red Solid: Lantern is fully charged.
- D) Charging time 8 Hours

Power bank function:

Designed to serve as a power bank for smart phones and other devices in an emergency (cords to specific devices not included)

Charge Your Device
USB Output (Cable not Included)



Charge Lantern
Micro USB Input (Cable Included)

Performance Index

FL1 STANDARD	HIGH	HIGH-MEDIUM	MEDIUM-LOW	LOW
	1800 LUMENS	750 LUMENS	370 LUMENS	80 LUMENS
	2h 15min	6h	13h 45min	22h 40min
	40m			

Battery Charge Options



BATTERY CARE: Your product is powered by a rechargeable battery. Do not leave fully charged battery connected to charger, since this will reduce its lifetime. Leaving product in extreme cold or heat will reduce battery life. For optimal performance store product at temperatures between 59°F to 77°F. Battery performance may be reduced in temperatures well below freezing. Fully charged batteries will lose charge over time, if left unused.

BATTERY WARNING: Rechargeable battery is built-in. Do not attempt to remove or replace battery. The battery in this product is at risk of fire, explosion, or may cause chemical burns if mistreated.