




Carabiner Flashlight Battery Replacement

Uses Battery Type: 4 x LR41

For Model/Part#:
41-3942
TG08-10132-MT3



1. Twist off top of flashlight and gently remove the small black round rubber piece with a silver dot in the middle.
2. Gently slide out the four tiny button batteries wrapped together. There is also a spring that has a narrow and wide side.
3. Put the spring with the wide side in first, and then put the four replacement batteries in making sure they are all facing the same direction and place them All with the flat side toward the spring.
4. Make sure the black round rubber piece has the silver dot protruding on the end so one side of it makes contact with the batteries and the other side of it makes contact with the bulb piece.
5. Push in the small black round rubber piece (make sure it lines up flush or a tiny bit above the metal opening)
(If the rubber piece is too much below the metal opening, it will not connect properly)
6. Remove the round white piece of paper from the inside of the top and then twist on the top