

# DORCY®

## PRO SERIES 1850 LUMEN RECHARGEABLE SPOTLIGHT

### Spotlight Parts



### Spotlight Operation

#### Operating Instruction

Please read these instructions carefully before use. Unless directions are followed physical injury or property damage may result. Save these instructions for further reference.

#### Operating

- Unlock the ON/OFF switch.
- Press the MODE switch once. The LED Rechargeable Spotlight will illuminate in a high beam (1850LM).
- Press the MODE switch twice. The LED Rechargeable Spotlight will illuminate in a medium beam (900LM).
- Press the MODE switch twice. The LED Rechargeable Spotlight will illuminate in a low beam (400LM).
- Press the MODE switch three times. The LED Rechargeable Spotlight will illuminate in a flashing beam (500LM).

**NOTE:** Before initial use, charge the LED Rechargeable Spotlight for at least 4 hours.

1. Disconnect the rear cover from the spotlight by turning it counter clockwise.
2. Directly connect USB cable into the designed socket in the back. A charge indicator light on the spotlight will turn on. When the light is fully charged, all four indicator bars will light up.
3. Disconnect the USB cable from the back of the spotlight. Attach rear cover to the spotlight.

### Performance Index

FL1 STANDARD	HIGH	MEDIUM	LOW
	1850 LUMENS	900 LUMENS	400 LUMENS
	3h 45min	10h	22h 45min
	440m	320m	200m

### Battery Charge Options

